


Run Flat




AREA:

CARCASS & LINER

CONDITION:

Discolouration, blistering, wrinkling and/or separations of the inner liner.



CAUSES:

- Continued operation while under-inflated and/or overloaded.
- Excessive under-inflation (close to a flat condition).
- Leaking rims (hair line cracks).
- Leaking valves.
- Penetrations.

RECOMMENDATIONS:

- Remove tyre from service.
- Check air pressure frequently. Do not re-inflate a tyre that is 30% or more under-inflated.
- Check for any nails embedded in tread or other external damage frequently.

HOW TO CHECK:

Check the outside and inside of tyre visually.

